
LEULARIS -

WIRING INSTRUCTIONS



WARNING

- 1. This is a 12 volt d.c. System ONLY
- 2. Connect red (+) wire to Positive
- 3. Connect black (-) wire to Negative
- 4. Plug in all wiring as per diagram
- 5. Connect reverse camera to Video 2 Only.

DO NOT CONNECT 12 VOLT SUPPLY UNTIL MONITOR AND CAMERA ARE CONNECTED

All Polaris Rear vision systems are a driver assistance device. They are not a substitute for driver responsibilty when reversing a vehicle.

OPTIONAL WIRING INSTRUCTIONS

- 1. Power hookup from reverse light. This enables the unit to operate automatically when reverse gear is selected.
- 2. Power hookup from accessory power. This allows continuous use, for people who tow a caravan etc
- 3. Reverse light and accessory power hookup with a changeover switch. This allows user to have either automatic or continuous use via a dash mounted switch
- 4. 24 12 VOLT Control box. This is for 24 volt systems to convert the voltage to 12 volt. (Optional Extra)

Please turn over for optional wiring diagrams